


CEN 3311 HEAT TRANSFER

HEAT TRANSFER AND ITS APPLICATIONS

- Almost all operations in chemical engineering involve the production or absorption of energy in the form of heat.
- Heat transfer is the science that seeks to predict the energy transfer that may take place between material bodies as a result of a temperature difference.



<u>Transport quantity</u>	<u>Physical phenomenon</u>	<u>Equation</u>
Momentum	Viscosity (Newtonian fluid)	$\tau = -\gamma \frac{\partial \rho v}{\partial x}$
Heat (energy)	Heat conduction (Fourier's law)	$\frac{q}{A} = -k \frac{\partial T}{\partial x}$
Mass	Molecular diffusion (Fick's law)	$J = -D \frac{\partial C}{\partial x}$

The principles of heat transfer are applied to the for heating, cooling evaporating and condensing.

Heat is the thermal energy in transit due to a spatial temperature difference.

There are three types of heat transfer mechanisms:

1. Conduction
2. Convection
3. Thermal Radiation

1. Concept of heat transfer

Heat transfer seeks to predict the energy transfer that may take place between material bodies as a result of a temperature differences. Heat transfer may take place by one or more of three modes: conduction, convection and radiation

Conduction

Fourier's law of heat conduction

$$q_x = -k_A A \frac{dT_A}{dx}$$

Where k is thermal conductivity of the wall's material , (W/m.K)


A is area of the Wall, (m²)

x is the heat flow direction , (m)

T is the temperature of the Wall , (°C)

The minus sign is inserted because heat must flow downhill on the temperature scale.

q	\rightarrow rate of heat flow in the direction normal to surface,	J/s, W
A	\rightarrow surface area,	m^2
x	\rightarrow distance normal to surface,	m
k	\rightarrow thermal conductivity,	W/mK
T	\rightarrow temperature,	$\text{T}^\circ\text{C, K}$



Convection

Convection is the mode of heat transfer between a solid surface and the adjacent fluid which is in motion, The convective heat transfer is associated with the displacement of the fluid element.

Convection is called forced convection if the fluid is forced to flow over the surface by a fan, wind, or the pump. In contrast, convection is called free convection if the fluid motion is caused by buoyancy force that is induced by density difference due to the variation of temperature in the fluid

Newton's law of heat convection

$$q_x = hA(T - T_w)$$

where h is convective heat transfer coefficient (W/m.K)

A is heat transfer area (m^2)

T_w is surface temperatures of the wall ($^{\circ}C$)

T is the bulk fluid temperature ($^{\circ}C$)

Radiation

Radiation is the energy emitted by matter in the form of electromagnetic waves as a result of the changes in the electronic configurations of the atoms or molecules. The maximum rate of radiation which can be emitted from a surface at an absolute temperature (T_s) is given by the *Stefan-Boltzmann law* as:

$$q_{\text{emit}} = \varepsilon \cdot \sigma \cdot A \cdot T_s^4$$

- Where $\sigma = 5.67 \times 10^{-8} \text{ W/m}^2 \cdot \text{K}^4$

σ is the *Stefan-Boltzmann constant* and ε is the *emissivity* of the surface. An idealized surface, which emits radiation at a maximum rate has $\varepsilon = 1$, is known as a *blackbody*.